





TIPS AND BEST PRACTICES

- DO NOT LET BATTERY RUN EMPTY.
 RECHARGE WHEN LED IS RED.
- USE THE PROVIDED USB CABLE AND CERTIFIED WALL CHARGER TO CHARGE THE BATTERY.
- DO NOT LEAVE BATTERY UNATTENDED WHILE CHARGING.
- TO CLEAN TANK:
 - UNSCREW TOP CAP AND REMOVE COIL
 - FILL TANK WITH WARM WATER AND SCREW TOP CAP ON
 - GENTLY SHAKE, WITH WATER INSIDE
 - UNSCREW CAP AND EMPTY WATER; REPEAT IF NECESSARY
 - AIR DRY COMPLETELY AND READY TO USE

SUPPORT

- f facebook.com/Innokin.Technology
- instagram.com/innokintechnology
- twitter.com/innokintech
- **ढ** reddit.com/r/innokin
- support@innokin.com