


- 1 ATTACH TANK
- 2 SLIDE CAP TO OPEN AND TOP FILL

REFILLING THE TANK




Push in the direction of the arrow, to slide open top cap



Carefully fill with e-liquid. Please wait 5 minutes before vaping

- 3 INSERT 20700 or 18650 (with adapter) BATTERY*
*FOLLOW BATTERY ORIENTATION




TIPS AND BEST PRACTICES

- BUY ONLY HIGH QUALITY BATTERIES FROM A TRUSTED SOURCE.
- ONLY USE A HIGH QUALITY 18650/20700 BATTERY CHARGER.
- DO NOT LEAVE BATTERIES UNATTENDED WHILE CHARGING. REMOVE BATTERY WHEN FULLY CHARGED.
- ALWAYS STORE BATTERIES SAFELY IN A SILICONE SLEEVE WHEN NOT IN USE.
- BATTERIES MUST ALWAYS BE STORED IN A PROTECTIVE SLEEVE OR CASE WHEN PLACED IN A POCKET OR BAG.
- DO NOT REMOVE THE BATTERY WRAP.
- IF THE BATTERY WRAP IS DAMAGED, REPLACE BATTERY IMMEDIATELY.
- IF THE WRAP IS DISCOLORED, REPLACE BATTERY.
- DO NOT USE DAMAGED BATTERIES.

SUPPORT

- facebook.com/Innokin.Technology
- instagram.com/innokintechnology
- twitter.com/innokintech
- reddit.com/r/innokin
- support@innokin.com




- 1 ATTACHER LE RÉSERVOIR
- 2 FAIRE GLISSER LE CAPUCHON POUR OUVRIR ET FAIRE LE PLEIN

REMPLISSAGE DU RÉSERVOIR




Poussez dans la direction de la flèche, pour ouvrir en faisant glisser le capuchon supérieur.



Remplissez d'e-liquide avec précaution. Veuillez patienter 5 minutes avant le vapotage.

- 3 INSÉRER UN ACCUMULATEUR 20700 ou 18650 (avec adaptateur)*
*RESPECTEZ L'ORIENTATION DE L'ACCUMULATEUR



CONSEILS ET MEILLEURES PRATIQUES

- ACHÉTEZ UNIQUEMENT DES ACCUMULATEURS DE HAUTE QUALITÉ CHEZ UNE SOURCE DE CONFIANCE.
- UTILISEZ UNIQUEMENT UN CHARGEUR D'ACCUMULATEUR 18650/20700 DE HAUTE QUALITÉ.
- NE LAISSEZ PAS L'ACCUMULATEUR SANS SURVEILLANCE PENDANT LA CHARGE. RETIREZ L'ACCUMULATEUR LORSQU'IL EST COMPLÈTEMENT CHARGÉ.
- CONSERVEZ TOUJOURS LES ACCUMULATEURS EN TOUTE SÉCURITÉ DANS UNE POCHETTE DE SILICONE LORSQUE VOUS NE LES UTILISEZ PAS.
- LES ACCUMULATEURS DOIVENT TOUJOURS ÊTRE CONSERVÉS DANS UNE POCHETTE OU UN BOÎTIER DE PROTECTION LORSQUE VOUS LES METTEZ DANS UNE POCHE OU UN SAC.
- NE RETIREZ PAS L'ENVELOPPE DE L'ACCUMULATEUR.
- SI L'ENVELOPPE DE L'ACCUMULATEUR EST ENDOMMAGÉE, REMPLACEZ L'ACCUMULATEUR IMMÉDIATEMENT.
- SI L'ENVELOPPE EST DÉCOLORÉE, REMPLACEZ L'ACCUMULATEUR.
- N'UTILISEZ PAS D'ACCUMULATEUR ENDOMMAGÉ.